



GNM3D Series

and

GNM3T Series

**COMMUNICATION
PROTOCOL**

Version 1 Revision 1

Index

| | | |
|----------|---|----------|
| 1.1 | Introduction | 3 |
| 1.2 | MODBUS functions | 3 |
| 1.2.1 | <i>Function 03h (Read Holding Registers)</i> | 3 |
| 1.2.2 | <i>Function 04h (Read Input Registers)</i> | 4 |
| 1.2.3 | <i>Function 06h (Write Single Holding Register)</i> | 4 |
| 1.2.4 | <i>Function 08h (Diagnostic with sub-function code 00h).....</i> | 5 |
| 1.2.5 | <i>Broadcast mode</i> | 5 |
| 1.3 | Application notes..... | 6 |
| 1.3.1 | <i>RS485 general considerations</i> | 6 |
| 1.3.2 | <i>MODBUS timing</i> | 6 |
| 2 | TABLES | 7 |
| 2.1 | Data format representation In Carlo Gavazzi instruments | 7 |
| 2.2 | Geometric representation..... | 7 |
| 2.3 | Maximum and minimum electrical values in GNM3 SERIES..... | 8 |
| 2.4 | Instantaneous variables and meters (grouped by variable type) | 9 |
| | Instantaneous variables and meters (grouped by phase)..... | 10 |
| 2.5 | Firmware version and revision code | 11 |
| 2.6 | GARO identification code..... | 11 |
| 2.7 | Programming parameter tables..... | 11 |
| 2.7.1 | <i>Password configuration menu</i> | 11 |
| 2.7.2 | <i>System configuration menu.....</i> | 11 |
| 2.7.3 | <i>PT and CT configuration menu.....</i> | 11 |
| 2.7.4 | <i>Dmd and pulse outs configuration menu</i> | 11 |
| 2.7.5 | <i>Other functions configuration menu.....</i> | 12 |
| 2.7.6 | <i>Active tariff selection.....</i> | 12 |
| 2.7.7 | <i>Serial port configuration menu.....</i> | 12 |
| 2.7.8 | <i>Reset commands.....</i> | 13 |
| 2.7.9 | <i>Serial number</i> | 13 |
| 2.7.10 | <i>Note</i> | 13 |

1.1 Introduction

The RS485 serial interface supports the MODBUS/JBUS (RTU) protocol. In this document only the information necessary to read/write from/to GNM3D and GNM3T series has been reported (not all the parts of the protocol have been implemented).

For a complete description of the MODBUS protocol please refer to the latest revision of the "Modbus_Application_Protocol" document that is downloadable from the www.modbus.org web site.

1.2 MODBUS functions

These functions are available on GNM3D and GNM3T SERIES:

- Reading of n "Holding Registers" (code 03h)
- Reading of n "Input Register" (code 04h)
- Writing of one "Holding Registers" (code 06h)
- Diagnostic (code 08h with sub-function code 00h)
- Broadcast mode (writing instruction on address 00h)

IMPORTANT:

- 1) In this document the "Modbus address" field is indicated in two modes:
 - 1.1) "**Modicom address**": it is the "6-digit Modicom" representation with Modbus function code 04 (Read Input Registers). It is possible to read the same values with function code 03 (Read Holding Registers) replacing the first digit ("3") with the number "4".
 - 1.2) "**Physical address**": it is the "word address" value to be included in the communication frame.
- 2) The functions 03h and 04h have exactly the same effect and can be used indifferently.
- 3) The communication parameters are to be set according to the configuration of the instrument (refer to GNM3D and GNM3T series instruction manuals)

1.2.1 Function 03h (Read Holding Registers)

This function is used to read the contents of a contiguous block of holding registers (word). The Request frame specifies the starting register address and the number of registers to be read. It is possible to read maximum 50 registers (words) with a single request, when not differently specified.

The register data in the response message are packed as two bytes per register (word), with the binary contents right justified within each byte. For each register, the first byte contains the high order bits (MSB) and the second contains the low order bits (LSB).

Request frame

| Description | Length | Value | Note |
|--------------------------------|---------|---------------------|----------------------|
| Physical address | 1 byte | 1 to F7h (1 to 247) | |
| Function code | 1 byte | 03h | |
| Starting address | 2 bytes | 0000h to FFFFh | Byte order: MSB, LSB |
| Quantity of registers (N word) | 2 bytes | 1 to 14h (1 to 20) | Byte order: MSB, LSB |
| CRC | 2 bytes | | |

Response frame (correct action)

| Description | Length | Value | Note |
|-----------------------------|-----------|---------------------|----------------------|
| Physical address | 1 byte | 1 to F7h (1 to 247) | |
| Function code | 1 byte | 03h | |
| Quantity of requested bytes | 1 byte | N word * 2 | |
| Register value | N*2 bytes | | Byte order: MSB, LSB |
| CRC | 2 bytes | | |

Response frame (incorrect action)

| Description | Length | Value | Note |
|------------------|---------|-------------------------------|--|
| Physical address | 1 byte | 1 to F7h (1 to 247) | Possible exception : 01h: illegal function |
| Function code | 1 byte | 83h | 02h: illegal data address |
| Exception code | 1 byte | 01h, 02h, 03h, 04h (see note) | 03h: illegal data value 04h: slave device failure |
| CRC | 2 bytes | | |

1.2.2 Function 04h (Read Input Registers)

This function code is used to read the contents of a contiguous block of input registers (word). The Request frame specifies the starting register address and the number of registers to be read. It is possible to read maximum 50 register (word) with a single request, when not differently specified.

The register data in the response message are packed as two bytes per register (word), with the binary contents right justified within each byte. For each register, the first byte contains the high order bits (MSB) and the second contains the low order bits (LSB).

Request frame

| Description | Length | Value | Note |
|--------------------------------|---------|---------------------|----------------------|
| Physical address | 1 byte | 1 to F7h (1 to 247) | |
| Function code | 1 byte | 04h | |
| Starting address | 2 bytes | 0000h to FFFFh | Byte order: MSB, LSB |
| Quantity of registers (N word) | 2 bytes | 1 to 14h (1 to 20) | Byte order: MSB, LSB |
| CRC | 2 bytes | | |

Response frame (correct action)

| Description | Length | Value | Note |
|-----------------------------|-----------|---------------------|----------------------|
| Physical address | 1 byte | 1 to F7h (1 to 247) | |
| Function code | 1 byte | 04h | |
| Quantity of requested bytes | 1 byte | N word * 2 | |
| Register value | N*2 bytes | | Byte order: MSB, LSB |
| CRC | 2 bytes | | |

Response frame (incorrect action)

| Description | Length | Value | Note |
|------------------|---------|---------------------|--|
| Physical address | 1 byte | 1 to F7h (1 to 247) | Possible exception : 01h: illegal function |
| Function code | 1 byte | 84h | 02h: illegal data address |
| Exception code | 1 byte | 01h, 02h, 03h, 04h | 03h: illegal data value 04h: slave device failure |
| CRC | 2 bytes | | |

1.2.3 Function 06h (Write Single Holding Register)

This function code is used to write a single holding register. The Request frame specifies the address of the register (word) to be written and its content.

The correct response is an echo of the request, returned after the register content has been written.

Request frame

| Description | Length | Value | Note |
|------------------|---------|---------------------|----------------------|
| Physical address | 1 byte | 1 to F7h (1 to 247) | |
| Function code | 1 byte | 06h | |
| Starting address | 2 bytes | 0000h to FFFFh | Byte order: MSB, LSB |
| Register value | 2 bytes | 0000h to FFFFh | Byte order: MSB, LSB |
| CRC | 2 bytes | | |

Response frame (correct action)

| Description | Length | Value | Note |
|------------------|---------|---------------------|----------------------|
| Physical address | 1 byte | 1 to F7h (1 to 247) | |
| Function code | 1 byte | 06h | |
| Starting address | 2 bytes | 0000h to FFFFh | Byte order: MSB, LSB |
| Register value | 2 bytes | 0000h to FFFFh | Byte order: MSB, LSB |
| CRC | 2 bytes | | |

Response frame (incorrect action)

| Description | Length | Value | Note |
|------------------|---------|---------------------|--|
| Physical address | 1 byte | 1 to F7h (1 to 247) | Possible exception : 01h: illegal function 02h: illegal data address 03h: illegal data value 04h: slave device failure |
| Function code | 1 byte | 86h | |
| Exception code | 1 byte | 01h, 02h, 03h, 04h | |
| CRC | 2 bytes | | |

1.2.4 Function 08h (Diagnostic with sub-function code 00h)

MODBUS function 08h provides a series of tests to check the communication system between a client (Master) device and a server (Slave), or to check various internal error conditions in a server. GNM3D Series supports only 0000h sub-function code (Return Query Data). With this sub-function the data passed in the request data field is to be returned (looped back) in the response. The entire response message should be identical to the request.

Request frame

| Description | Length | Value | Note |
|-----------------------|-------------------|---------------------|----------------------|
| Physical address | 1 byte | 1 to F7h (1 to 247) | |
| Function code | 1 byte | 08h | |
| Sub-function | 2 bytes | 0000h | |
| Data (N word) | N *2 bytes | Data | Byte order: MSB, LSB |
| CRC | 2 bytes | | |

Response frame (correct action)

| Description | Length | Value | Note |
|-----------------------|-------------------|--------------------|----------------------|
| Physical address | 1 byte | 1 to F7 (1 to 247) | |
| Function code | 1 byte | 08h | |
| Sub-function | 2 bytes | 0000h | |
| Data (N word) | N *2 bytes | Data | Byte order: MSB, LSB |
| CRC | 2 bytes | | |

Response frame (incorrect action)

| Description | Length | Value | Note |
|------------------|---------|---------------------|--|
| Physical address | 1 byte | 1 to F7h (1 to 247) | Possible exception : 01h: illegal function 02h: illegal data address 03h: illegal data value 04h: slave device failure |
| Function code | 1 byte | 88h | |
| Exception code | 1 byte | 01h, 02h, 03h, 04h | |
| CRC | 2 bytes | | |

1.2.5 Broadcast mode

In broadcast mode the master can send a request (command) to all the slaves. No response is returned to broadcast requests sent by the master. It is possible to send the broadcast message only with function code 06h using address 00h.

1.3 Application notes

1.3.1 RS485 general considerations

1. To avoid errors due to the signal reflections or line coupling, it is necessary to terminate the bus at the beginning (master side, if not already embedded, by inserting a 120 ohm 1/2W 5% resistor between line B and A) and at the end (in GNM3D and GNM3T series interface by connecting the terminal A-with the terminal T in the last instrument).
2. The network termination is necessary even in case of point-to-point connection and/or of short distances.
3. For connections longer than 1000m or if in the network there are more than 160 instruments (with 1/5 unit load as used in GNM3D and GNM3T series interface), a signal repeater is necessary.
4. For bus connection it is suggested to use an AWG24 balanced pair cable and to add a third wire for GND connection. If a shielded cable is used, connect the shield to GND.
5. The GND should be connected to ground only at the host side.
6. If an instrument does not answer within the "max answering time", it is necessary to repeat the query. If the instrument does not answer after 2 or 3 consecutive queries, it is to be considered as not connected, faulty or reached with a wrong address. The same consideration is valid in case of CRC errors or incomplete response frames.

1.3.2 MODBUS timing




Fig. 1 : 2-wire timing diagram

| Timing characteristics of reading function: | ms |
|--|----------|
| T response: Max answering time | 500 ms |
| T response: Typical answering time | 40 ms |
| T delay: Minimum time before a new query | 3,5 char |
| T null: Max interruption time during the request frame | 2,5 char |

2 TABLES

2.1 Data format representation

The variables are represented by integers or floating numbers, with 2's complement notation in case of "signed" format, using the following:

| Format | IEC data type | Description | Bits | Range |
|------------|---------------|---------------------------------|------|---|
| INT16 | INT | Integer | 16 | -32768 .. 32767 |
| UINT16 | UINT | Unsigned integer | 16 | 0 .. 65535 |
| INT32 | DINT | Double integer | 32 | -2 ³¹ .. 2 ³¹ |
| UINT32 | UDINT | Unsigned double integer | 32 | 0 .. 2 ³² -1 |
| UINT64 | ULINT | Unsigned long integer | 64 | 0 .. 2 ⁶⁴ -1 |
| IEEE754 SP | | Single-precision floating-point | 32 | (-1+[1-2 ⁻²³])x2 ¹²⁷ .. 2 ¹²⁸ |

For all the formats the byte order (inside the single word) is MSB->LSB. In INT32, UINT32 and UINT64 formats, the word order is LSW-> MSW.

2.2 Geometric representation

According to the signs of the power factor, the active power P and the reactive power Q, it is possible to obtain a geometric representation of the power vector, as indicated in the drawing below, according to EN 60253-23:




Fig. 2 : Geometric Representation

According to the measurement mode (easy connection or bidirectional), the following sign convention is used in GNM3D and GNM3T series.

- Easy connection mode
 - o I always >0
 - o P always >0
 - o kWh always increasing (GNM3T and GNM3D version)
 - o **kvarh increases only when Q>0**
 - o PF only with C and L (without sign) indication
- Bidirectional mode)
 - o I < or >0 (with indication of “-“ sign)
 - o P < or >0 (with indication of “-“ sign)
 - o kWh+ increasing only when P > 0 (only when Measurement menu is set to “B” in the GNM3D non-MID version or in the MID version GNM3D-LP)
 - o kWh- increasing only when P < 0
 - o kvarh+ increasing only when Q > 0
 - o kvarh- increasing only when Q < 0
 - o PF with ±C or ±L indication

| Application | Real measurement | Displayed values | Displayed energies | Notes |
|----------------------|------------------|---------------------|--|--|
| Easy connection Mode | Quadrant I | A, W, var, L PF | kWh increases kvarh increases | Measurement A or MID model GNM3... |
| | Quadrant II | A, W, -var, C PF | kWh increases kvarh does not increase | Measurement A or MID model GNM3... |
| | Quadrant III | A, W, var, L PF | kWh increases kvarh increases | Measurement A or MID model GNM3... |
| | Quadrant IV | A, W, -var, C PF | kWh increases kvarh does not increase | Measurement A or MID model GNM3... |
| Bidirectional Mode | Quadrant I | A, W, var, +L PF | kWh+ increases kvarh+ increases | Measurement B in the non-Mid model or MID model GNM3D-LP |
| | Quadrant II | -A, -W, +var, -C PF | kWh- increases kvarh+ increases | Measurement B in the non-Mid model or MID model GNM3D-LP |
| | Quadrant III | -A, -W, -var, -L PF | kWh- increases kvarh- increases | Measurement B in the non-Mid model or MID model GNM3D-LP |
| | Quadrant IV | A, W, -var, +C PF | kWh+ increases kvarh- increases | Measurement B in the non-Mid model or MID model GNM3D-LP |

2.3 Maximum and minimum electrical values in GNM3D and GNM3T SERIES

The maximum electrical input values are reported in the following table. If the input is above the maximum value the display shows “EEE”.

Table 2.1-1

| | GNM3T | | GNM3D | |
|------|---|-----------|-----------|-----------|
| | Max value | Min value | Max value | Min value |
| VL-N | 485V | 0 | 299V | 0 |
| VL-L | 840V | 0 | 518V | 0 |
| A | 6,5A (displ. value = 6.5 A x CT ratio) | 0 | 78A | 0 |
| VT | 1000 | 1 | / | / |
| CT | 1000 | 1 | / | / |

The overflow indication “EEE” is displayed when the MSB value of the relevant variable is 7FFFFFFFh (word order FFFF 7FFF).

Note: The product (CT ratio)x(VT ratio) shall be automatically limited to prevent overflow of kW indication on the meter (max power = 9999 kW).

2.4 Instantaneous variables and meters (grouped by variable type)

MODBUS: read only mode with functions code 03 and 04

Table 2.4-1

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-----------------|------------------|----------------|--------------------|-------------|--|
| 300001 | 0000h | 2 | V L1-N | INT32 | Value weight: Volt*10 |
| 300003 | 0002h | 2 | V L2-N | INT32 | |
| 300005 | 0004h | 2 | V L3-N | INT32 | |
| 300007 | 0006h | 2 | V L1-L2 | INT32 | |
| 300009 | 0008h | 2 | V L2-L3 | INT32 | |
| 300011 | 000Ah | 2 | V L3-L1 | INT32 | |
| 300013 | 000Ch | 2 | A L1 | INT32 | |
| 300015 | 000Eh | 2 | A L2 | INT32 | |
| 300017 | 0010h | 2 | A L3 | INT32 | |
| 300019 | 0012h | 2 | kW L1 | INT32 | |
| 300021 | 0014h | 2 | kW L2 | INT32 | Value weight: Watt*10 |
| 300023 | 0016h | 2 | kW L3 | INT32 | |
| 300025 | 0018h | 2 | kVA L1 | INT32 | |
| 300027 | 001Ah | 2 | kVA L2 | INT32 | Value weight: VA*10 |
| 300029 | 001Ch | 2 | kVA L3 | INT32 | |
| 300031 | 001Eh | 2 | kvar L1 | INT32 | |
| 300033 | 0020h | 2 | kvar L2 | INT32 | Value weight: var*10 |
| 300035 | 0022h | 2 | kvar L3 | INT32 | |
| 300037 | 0024h | 2 | V L-N sys | INT32 | |
| 300039 | 0026h | 2 | V L-L sys | INT32 | Value weight: Volt*10 |
| 300041 | 0028h | 2 | kW sys | INT32 | |
| 300043 | 002Ah | 2 | kVA sys | INT32 | |
| 300045 | 002Ch | 2 | kvar sys | INT32 | Value weight: var*10 |
| 300047 | 002Eh | 1 | PF L1 | INT16 | |
| 300048 | 002Fh | 1 | PF L2 | INT16 | |
| 300049 | 0030h | 1 | PF L3 | INT16 | |
| 300050 | 0031h | 1 | PF sys | INT16 | Negative values correspond to exported active power, positive values correspond to imported active power. Value weight: PF*1000 |
| 300051 | 0032h | 1 | Phase sequence | INT16 | |
| | | | | | The value -1 corresponds to L1-L3-L2 sequence, the value 0 corresponds to L1-L2-L3 sequence. The phase sequence value is meaningful only in a 3-phase system |
| 300052 | 0033h | 1 | Hz | INT16 | Value weight: Hz*10 |
| 300053 | 0034h | 2 | kWh (+) TOT | INT32 | Value weight: kWh*10 |
| 300055 | 0036h | 2 | Kvarh (+) TOT | INT32 | Value weight: kvarh*10 |
| 300057 | 0038h | 2 | kW dmd | INT32 | Value weight: Watt*10 |
| 300059 | 003Ah | 2 | kW dmd peak | INT32 | Value weight: Watt*10 |
| 300061 | 003Ch | 2 | kWh (+) PARTIAL | INT32 | Value weight: kWh*10 |
| 300063 | 003Eh | 2 | Kvarh (+) PARTIAL | INT32 | Value weight: kvarh*10 |
| 300065 | 0040h | 2 | kWh (+) L1 | INT32 | Value weight: kWh*10 |
| 300067 | 0042h | 2 | kWh (+) L2 | INT32 | Value weight: kWh*10 |
| 300069 | 0044h | 2 | kWh (+) L3 | INT32 | Value weight: kWh*10 |
| 300071 | 0046h | 2 | kWh (+) t1 | INT32 | Value weight: kWh*10 |
| 300073 | 0048h | 2 | kWh (+) t2 | INT32 | Value weight: kWh*10 |
| 300079 | 004Eh | 2 | kWh (-) TOT | INT32 | Value weight: kWh*10 |
| 300081 | 0050h | 2 | kvarh (-) TOT | INT32 | Value weight: kvarh*10 |
| 300091 | 005Ah | 2 | Run hour meter | INT32 | Value weight: hours*100, only GNM3T series |

Instantaneous variables and meters (grouped by phase)

MODBUS: read only mode with functions code 03 and 04

Table 2.5-1

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-------------------------------------|------------------|----------------|--------------------|-------------|--|
| System variables | | | | | |
| 300249 | 00F8h | 2 | A n | INT32 | Value weight: Ampere*1000, only GNM3T series |
| 300255 | 00FEh | 2 | Run hour meter | INT32 | Value weight: hours*100, only GNM3T series |
| 300259 | 0102h | 2 | V L-N sys | INT32 | Value weight: Volt*10 |
| 300261 | 0104h | 2 | V L-L sys | INT32 | Value weight: Volt*10 |
| 300263 | 0106h | 2 | kW sys | INT32 | Value weight: Watt*10 |
| 300265 | 0108h | 2 | kVA sys | INT32 | Value weight: VA*10 |
| 300267 | 010Ah | 2 | kvar sys | INT32 | Value weight: var*10 |
| 300269 | 010Ch | 2 | PF sys | INT32 | (*) Value weight: PF*1000 |
| 300271 | 010Eh | 2 | Phase sequence | INT32 | The value -1 corresponds to L1-L3-L2 sequence, the value 0 corresponds to L1-L2-L3 sequence. The phase sequence value is meaningful only in a 3-phase system |
| 300273 | 0110h | 2 | Hz | INT32 | Value weight: Hz*10 |
| Total energies and dmd power | | | | | |
| 300275 | 0112h | 2 | kWh (+) TOT | INT32 | Value weight: kWh*10 |
| 300277 | 0114h | 2 | Kvarh (+) TOT | INT32 | Value weight: kvarh*10 |
| 300279 | 0116h | 2 | kWh (-) TOT | INT32 | Value weight: kWh*10 |
| 300281 | 0118h | 2 | kvarh (-) TOT | INT32 | Value weight: kvarh*10 |
| 300283 | 011Ah | 2 | kW dmd | INT32 | Value weight: Watt*10 |
| 300285 | 011Ch | 2 | kW dmd peak | INT32 | Value weight: Watt*10 |
| Phase 1 variables | | | | | |
| 300287 | 011Eh | 2 | V L1-L2 | INT32 | Value weight: Volt*10 |
| 300289 | 0120h | 2 | V L1-N | INT32 | Value weight: Volt*10 |
| 300291 | 0122h | 2 | A L1 | INT32 | Value weight: Ampere*1000 |
| 300293 | 0124h | 2 | kW L1 | INT32 | Value weight: Watt*10 |
| 300295 | 0126h | 2 | kVA L1 | INT32 | Value weight: VA*10 |
| 300297 | 0128h | 2 | kvar L1 | INT32 | Value weight: var*10 |
| 300299 | 012Ah | 2 | PF L1 | INT32 | (*) Value weight: PF*1000 |
| Phase 2 variables | | | | | |
| 300301 | 012Ch | 2 | V L2-L3 | INT32 | Value weight: Volt*10 |
| 300303 | 012Eh | 2 | V L2-N | INT32 | Value weight: Volt*10 |
| 300305 | 0130h | 2 | A L2 | INT32 | Value weight: Ampere*1000 |
| 300307 | 0132h | 2 | kW L2 | INT32 | Value weight: Watt*10 |
| 300309 | 0134h | 2 | kVA L2 | INT32 | Value weight: VA*10 |
| 300311 | 0136h | 2 | kvar L2 | INT32 | Value weight: var*10 |
| 300313 | 0138h | 2 | PF L2 | INT32 | (*) Value weight: PF*1000 |
| Phase 3 variables | | | | | |
| 300315 | 013Ah | 2 | V L3-L1 | INT32 | Value weight: Volt*10 |
| 300317 | 013Ch | 2 | V L3-N | INT32 | Value weight: Volt*10 |
| 300319 | 013Eh | 2 | A L3 | INT32 | Value weight: Ampere*1000 |
| 300321 | 0140h | 2 | kW L3 | INT32 | Value weight: Watt*10 |
| 300323 | 0142h | 2 | kVA L3 | INT32 | Value weight: VA*10 |
| 300325 | 0144h | 2 | kvar L3 | INT32 | Value weight: var*10 |
| 300327 | 0146h | 2 | PF L3 | INT32 | (*) Value weight: PF*1000 |
| Other energies | | | | | |
| 300329 | 0148h | 2 | kWh (+) PARTIAL | INT32 | Value weight: kWh*10 |
| 300331 | 014Ah | 2 | Kvarh (+) PARTIAL | INT32 | Value weight: kvarh*10 |
| 300333 | 014Ch | 2 | kWh (+) L1 | INT32 | Value weight: kWh*10 |
| 300335 | 014Eh | 2 | kWh (+) L2 | INT32 | Value weight: kWh*10 |
| 300337 | 0150h | 2 | kWh (+) L3 | INT32 | Value weight: kWh*10 |
| 300339 | 0152h | 2 | kWh (+) t1 | INT32 | Value weight: kWh*10 |
| 300341 | 0154h | 2 | kWh (+) t2 | INT32 | Value weight: kWh*10 |

Note *: Negative values correspond to exported active power, positive values correspond to imported active power.

Note Table 2.4-1 and 2.5-1 are equivalent and includes a copy of the same variable values.

Note For meters that support also 1-phase and 2-phase systems, the values relevant to phase 2 and 3 can still be read with a valid value, equal to "0"

Programming parameter note: reading values in addresses not specified in the below tables returns an illegal data address exception.

2.5 Firmware version and revision code

MODBUS: read only mode with functions code 03 and 04 limited to a word at a time

Table 2.6-1

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-----------------|------------------|----------------|--------------------|-------------|-----------------------------|
| 300771 | 0302h | 1 | Version code | UINT 16 | Value=1: Version "B" Modbus |
| 300772 | 0303h | 1 | Revision code | UINT 16 | Value=0: Revision "0" etc. |

2.6 GARO identification code

MODBUS: read only mode with functions code 03 and 04 limited to a word at a time

Table 2.7-1

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-----------------|------------------|----------------|--------------------------|-------------|-----------------|
| 300012 | 000Bh | 1 | Garo identification code | UINT 16 | See table 2.7-2 |

Table 2.7-2

| Complete item number | GARO identification code |
|----------------------|--------------------------|
| GNM3D-RS485 | 341 |
| GNM3T-RS485 | 342 |

2.7 Programming parameter tables

2.7.1 Password configuration menu

MODBUS: read and write mode

Table 2.8-1

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-----------------|------------------|----------------|--------------------|-------------|---|
| 304097 | 1000h | 1 | PASSWORD | UINT 16 | Minimum valid value: 0d Maximum valid value: 9999d |

2.7.2 System configuration menu

MODBUS: read and write mode

Table 2.8-2

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-----------------|------------------|----------------|--------------------|-------------|--|
| 304099 | 1002h | 1 | Measuring system | UINT 16 | Value=0: "3Pn" (3-phase with neutral) Value=1: "3P" (3-phase without neutral) Value=2: "2P" (2-phase with neutral) |

2.7.3 PT and CT configuration menu

MODBUS: read and write mode

Table 2.8-3

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-----------------|------------------|----------------|---------------------------|-------------|--|
| 304100 | 1003h | 2 | Current transformer ratio | UINT 32 | Value min = 10 (CT=1,0) Value max = 10000 (CT=1000.0) |
| 304102 | 1005h | 2 | Voltage transformer ratio | UINT 32 | Value min = 10 (VT=1,0) Value max = 10000 (VT=1000.0) |

2.7.4 Dmd and pulse outs configuration menu

MODBUS: read and write mode

Table 2.8-4

| Modicom | Physical | Length | VARIABLE | Data | Notes |
|---------|----------|--------|----------|------|-------|
|---------|----------|--------|----------|------|-------|

| address | address | (words) | ENG. UNIT | Format | |
|---------|---------|---------|--|---------|---------------------------------|
| | 1010h | 2 | Integration time for dmd power calculation | UINT 32 | Value min = 1 Value max = 30 |

2.7.5 Other functions configuration menu

MODBUS: read and write mode

Table 2.8-5

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-----------------|------------------|----------------|--|-------------|--|
| 304353 | 1100h | 1 | Display mode | UINT 16 | Value min = 0 (Full, default) Value max = 1 (Easy) Any other value = Full |
| 304354 | 1101h | 1 | Tariff management enabling | UINT 16 | Value min = 0 (OFF) Value max = 1 (ON) Any other value = OFF |
| 304355 | 1102h | 1 | Home page selection | UINT 16 | Value min = 0 (page 0, default) Value max = 19 (page 19) Restrictions in case of display mode = Easy Any other value = page 0 In ET always = 0 |
| 304356 | 1103h | 1 | Measurement mode selection | UINT 16 | Value min = 0 (A) Value max = 1 (B) Any other value = A |
| 304357 | 1104h | 1 | Wrong connection (Installing help) management enabling | UINT 16 | Value min = 0 (ON) Value max = 1 (OFF) Any other value = ON |
| 304358 | 1105h | 1 | Wrong connection (installing help) status | UINT 16 | Bit 0 = 1 means: Wrong voltage sequence Bit 1 = 1 means: Phase 1 inverted Bit 2 = 1 means: Phase 2 inverted Bit 3 = 1 means: Phase 3 inverted Bit 4 = 1 means: Phases 1 and 2 exchanged Bit 5 = 1 means: Phases 1 and 3 exchanged Bit 6 = 1 means: Phases 2 and 3 exchanged Bit 7 = 1 means: Phases 1, 2, 3 exchanged More than 1 bit can be 1 In any case a sequence of wiring modifications is needed until the wiring is correct (all bit=0) |

2.7.6 Active tariff selection

MODBUS: read and write mode

Table 2.8-6

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-----------------|------------------|----------------|---|-------------|---|
| 304608 | 1200h | 1 | Tariff mode selection (tariff management via digital input or serial comm.) | UINT 16 | Value min = 0 (via digital inputs) Value max = 1 (via serial comm.) Any other value = via digital in. |
| 304609 | 1201h | 1 | Tariff number selection via serial comm. | UINT 16 | Value min = 1 (tariff 1) Value max = 2 (tariff 2) Any other value = tariff 1 If 1200h = 0 (tariff via digital input), this parameter is "read only" mode |

2.7.7 Serial port configuration menu

MODBUS: read and write mode

Table 2.8-7

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-----------------|------------------|----------------|--------------------------|-------------|---|
| 308193 | 2000h | 1 | RS485 instrument address | UINT 16 | Value min = 1 (default) Value max = 247 Any other value = 1 |
| 308194 | 2001h | 1 | RS485 baud rate | UINT 16 | Value 1 = 9.6 kbps (default) Value 2 = 19.2 kbps Value 3 = 38.4 kbps Value 4 = 57.6 kbps Value 5 = 115.2 kbps Any other value = 9.6 kbps |
| 308195 | 2002h | 1 | RS485 parity | UINT 16 | Value 1= no parity (default) Value 2 = even parity Any other value = no parity |

| | | | | | |
|--------|-------|---|---|---------|---|
| 308196 | 2003h | 1 | RS485 Stop bit | UINT 16 | Value 0 = 1 stop bit Value 1= 1 (default) Value 2 =2 (only if parity is even) Any other value = 1 stop bit |
| 308197 | 2004h | 1 | Max number of words readable with a single Modbus request | UINT 16 | Value = 50 (words) |

Note: The number of stop bits is fixed to "1" if parity is EVEN.

2.7.8 Reset commands

MODBUS: read and write mode

Table 2.8-8

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-----------------|------------------|----------------|--|-------------|--|
| 316385 | 4000h | 1 | Reset of all partial and tariff meters, kWmdm and kWmdmdm peak | UINT 16 | Value=0: reset done Value=1: execute the command All other values produce no effects |
| 316386 | 4001h | 1 | Reset of total energy meters (only for non-MID versions) | UINT 16 | Value=0: reset done Value=1: execute the command All other values produce no effects |

2.7.9 Serial number

MODBUS: read only mode

Table 2.8-9

| Modicom address | Physical address | Length (words) | VARIABLE ENG. UNIT | Data Format | Notes |
|-----------------|------------------|----------------|--|-------------|------------------------------------|
| 320481 | 5000h | 1 | Letter 1 (from SX) Letter 2 (from SX) | | MSB: ASCII code LSB: ASCII code |
| 320482 | 5001h | 1 | Letter 3 (from SX) Letter 4 (from SX) | | MSB: ASCII code LSB: ASCII code |
| 320483 | 5002h | 1 | Letter 5 (from SX) Letter 6 (from SX) | | MSB: ASCII code LSB: ASCII code |
| 320484 | 5003h | 1 | Letter 7 (from SX) Letter 8 (from SX) | | MSB: ASCII code LSB: ASCII code |
| 320485 | 5004h | 1 | Letter 9 (from SX) Letter 10 (from SX) | | MSB: ASCII code LSB: ASCII code |
| 320486 | 5005h | 1 | Letter 11 (from SX) Letter 12 (from SX) | | MSB: ASCII code LSB: ASCII code |
| 320487 | 5006h | 1 | Letter 13 (from SX) | | MSB: ASCII code |

2.7.10 Note

The default value shall be automatically assigned to the parameters when an out-of-range or invalid value is written.